


# FURNACE MODULE



| MODEL        | CABINET DIMENSIONS |    |    | DUCT OPENING |        | DUCT LOCATION |       | WEIGHT |       |
|--------------|--------------------|----|----|--------------|--------|---------------|-------|--------|-------|
|              | A                  | B  | C  | D            | E      | F             | G     | SHIP   | OPER. |
| 600-800 NSS  | 39                 | 62 | 56 | 19-1/2       | 49-5/8 | 6-3/16        | 8-1/8 | 1000   | 1000  |
| 900-1200 NSS | 39                 | 62 | 84 | 19-1/2       | 49-5/8 | 6-3/16        | 8-1/8 | 1500   | 1500  |